

NOTES:

- FFL OF TOILETS & BALCONIES SHOULD BE 25MM LOWER THAN THE FFL OF RESPECTIVE FLOORS.
- CONMIX MOYA PROOF WS2/CONMIX MOYA PROOF HF WATER PROOFING TO BE PROVIDED IN TOILETS, BALCONIES & ROOF TERRACE PRIOR TO TILING

FINISHES–

- FLOORS – 600MM X 600MM HOMOGENOUS FLOOR TILES WITH CONMIX TILE ADHESIVE C800.
- TOILET FLOORS– 300MM X 300MM NON SKID CERAMIC FLOOR TILES WITH CONMIX TILE ADHESIVE C500.
- TOILET WALLS – 300MM X 300MM CERAMIC WALL TILES UP TO CEILING HEIGHT WITH CONMIX TILE ADHESIVE C500. USE CONMIX TILE JOINT FILLER GROUT OF APPROPRIATE COLOR FOR GROUTING JOINTS BETWEEN TILES

- APPLY CONMIX MOYA SHIELD RBE BETWEEN ALL EXTEND WALL AND SLAB JOINT FOR WATER PROOFING
- ADD CONMIX MEGA FLOW MP TO ALL INTERNAL/ EXTERNAL PLASTER, WET AREA PLASTER